



LEGENDARY  
RELIABILITY  
SINCE 1927

## INSTRUCTIONS

Changing or Replacing Inserts on the  
**PETOL<sup>®</sup> HOSEDAWG<sup>™</sup>**  
HDG-HA1 HANDLE ASSEMBLY

1. Remove the 3 black set screws from the side of the Handle Assembly.
2. Unscrew (counterclockwise) the Insert. (Black part with the teeth)
3. Reverse the process to install the insert size required.

**NOTE:** Insert should be "hand tight."  
Set screws should be slightly tighter.

Only the 2" or 2-1/2", 3" and 4" Inserts  
can be changed or replaced on the  
HDG-HA1 Handle Assembly.