


PETOL™ SUCKEROD TRANSFER – QTX Parts List



Item	Qty.	Part Number	Description
*1	1	QB1A	Body 5/8" suckerrod
*1	1	QB2A	Body 3/4, 7/8" suckerrod
*1	1	QB2RA	Body 3/4, 7/8" EL suckerrod
*1	1	QB4A	Body 1" suckerrod
*1	1	QB5A	Body 1-1/8" suckerrod
2	2	HXB01	Thrust bearing
3	1	HU03	Bushing
4	2	HXOR02	o-ring
5	1	HXN009	Slotted nut only
6	2	HXW016	Flat washer only
7	1	HXS054	Eyebolt with washers, nut and spring pin
8	1	QI5	Inner safety ring
9	1	QO5	Outer safety ring
10	2	HXS055	Safety ring screw
11	1	HXP007	Slotted spring pin only
12	1	HXG006	Grease fitting

*Transfer bodies are not available as individual components.

QTX-KIT Repair Kit	
Item	Qty.
2	2
3	1
4	2
5	1
6	2
7	1

QTRK5 Ring Kit	
Item	Qty.
8	1
9	1
10	2



4450 S. Hwy. 6 | P.O. Box 192
Clifton, TX 76634 | USA
www.PETOL.com

sales@petol.com | 254.675.8651