PETOL® SURGRIP® FRICTION VISE – ZV55-54 Parts List



PETOL®

4450 S. Hwy. 6 | P.O. Box 192
Clifton, TX 76634 | USA
www.PETOL.com

sales@petol.com | 254.675.8651

Rev: A

PETOL® SURGRIP® FRICTION VISE – ZV55-54 Parts List

Item	Qty.	Part Number	Description
1	1	ZV55-0-1	Base
2	1	ZV55-4-2	Lower jaw
3	1	ZV55-6-00	Clamping arm (standard)
3	1	ZV55-6-60	Clamping arm (0.060” oversize)
3	1	ZV55-6-120	Clamping arm (0.120” oversize)
4	1	ZV55-4-1	Upper jaw
5	1	ZV55-9-10	Clamping screw
6	1	ZV55-5-4A	Bearing nut assembly
6A	1	ZV55-5-40	Bearing nut handle only
6B	1	ZV35-5-21	Bearing nut handle grip only
6C	1	ZV35-5-27	Bearing nut sleeve only
6D	1	ZV35-5-28	Bearing nut clip ring only
6E	1	ZV35-5-29R	Bearing nut thrust bearing only
6F	1	HB53	Bearing nut bolt only
6G	1	HXN020	Bearing nut jam nut only
6H	1	HXW006	Bearing nut lock washer only
7	1	HU50	Bushing
8	1	HG14	Spring guide
9	1	HS07	Spring
10	1	ZV35-0-4	Set screw
11	2	ZV55-8	Vise bushing plunger
12	4	ZV35-10-1	Vise bushing key
13	4	ZV55-10-2	Vise bushing key screw
14	1	HP007	Clamping screw pin with klipring
15	2	HP030	Jaw and clamping arm pins with kliprings
16	5	HXKR062	Klipring only

PETOL®

4450 S. Hwy. 6 | P.O. Box 192
Clifton, TX 76634 | USA
www.PETOL.com

sales@petol.com | 254.675.8651